

MS-1010(M620) Instant ON installation Guide

To install Instant On function, it requires at least 200MB clean and non-partitioned space. The Instant ON installation CD is bootable. If you are going to install the Instant On to an empty HDD, it will create a 200MB partition itself and install the Instant On to the partition. If you are going to install the Instant On to a non-empty HDD, make sure you leave at least 200MB free and non-partitioned space.

Procedure:

- 1 Put the installation CD and power on the system, the system will boot from the installation CD.
- 2 Select language and then press Enter
- 3 Installation progress:
- 4 Install complete, press Enter to shut down.





Installation Complete

Please press "Enter" to shut down!